+7 (351) 700-13-80 +7 (351) 700-13-79

454091, Russian Federation, Chelyabinsk, 25 Tsvillinga Street

> sales@molnija.shop www.molnija-ltd.ru www.molnija.shop







Name of the authorized service centre				
The following steps have been taken in troubleshooting				
Service centre employee	Date			
(Signature, full name)				
Owner	Date			
Owner	Date			
(Signature, full name)				

WARRANTY CARD

SERIAL NUMBER

All warranty claims for repairs must be accompanied by a warranty card which has been filled out by both the buyer and the vendor who sold the watch.

STAMP H	RE	BUYER
Address and phone number (trading organization)		
VENDOR name of trading organization		
DATE OF SALE		

I have read and agree with the terms of use. I do not have any complaints regarding the appearance or the performance of the watch.

ATTENTION! THE WARRANTY CARD IS NOT VALID WITHOUT THE VENDOR'S STAMP!

DESCRIPTION AND INSTRUCTIONS

The Etude wrist watch comes equipped with the 3603 manually wound shock-resistant mechanical movement.

1. WINDING

Winding is performed by turning the crown in a clockwise direction while the crown is in the first position. Full winding takes 23 turns of the crown. Be sure to stop winding as soon as any resistance is felt.

IMPORTANT: Continuing to wind the watch after feeling resistance can lead to damage of the spring. All repairs necessitated by overwinding will be made at the customer's expense.

The provided power reserve is approximately 40 hours. We recommend winding once per day.

2. SETTING THE CURRENT TIME

Pull out the crown to the second position. Set the current time by turning the crown in a counter-clockwise direction.

After setting the current time return the crown to the first position by pressing the crown towards the case.

DIRECTIONS FOR USE, CARE AND STORAGE

1. WATER RESISTANCE

The Etude watches are water resistant to 5 ATM. They are resistant to rain and other accidental exposure to water such as handwashing. Do not swim, snorkel, or scuba dive with this watch.

IMPORTANT: NEVER PULL OUT THE CROWN WHILE THE WATCH IS WET.

Over time the normal wear on the watch will affect the overall water resistance. We recommend checking the watch at an authorized service center once a year to ensure a high level of water resistance and avoid accidental damage.

EXCLUSIONS

Warranty does not cover:

- Crystal and strap
- Problems arising from use of the watch (scratches on the crystal, color changes of non-metallic straps and bracelets etc)
- Any damage caused from improper use of the watch, lack of maintenance or mishandling (scratches, cracks, dents, etc)
- Any unauthorized attempts to repair the watch and/or change the appearance or construction of the watch
- Water damage caused from improper use of the crown

CONDITIONS OF WARRANTY

The warranty covers only those watches sold by authorized dealers.

Warranty lasts for 1 year from date of purchase. The warranty covers material and assembly defects. In the event of a problem falling under the conditions of the warranty the manufacturer will replace the consumer. If a repair is impossible, the manufacturer will replace the watch with an identical one, or one with the same characteristics. Repairs should take place only in authorized centers. To find an authorized service center, contact your local retailer.

2. CARE

The watch (excluding the strap) should regularly be washed with a wet, soapy rag.

3. PRECAUTIONS

- Never try to open the watch or remove the case back
- The watch should be checked at least once a year for resistance to water and dust. If necessary, replacement of the gaskets should be performed only in authorized service centers.
- Before submerging the watch in water, make sure the crown is in the first position.
- If water enters the case, bring the watch to an authorized service center as soon as possible.
- Do not subject the watch to extreme conditions (above 60 degrees Celsius or below -5 degrees Celsius). While the watch is being worn body heat protects it from extreme temperature changes.
- Do not drop, hit, or strike the watch.
- Do not fasten the strap too tightly. The watch should be fastened as to allow a finger between the watch strap and arm.
- The watch should be kept in a dry place.

- Prevent the watch from being exposed to gasoline, cleaning supplies, aerosols, paints, etc, as they may react with it and damage the gaskets, case and/or its coating.
- The sapphire crystal has a special anti-scratch coating but can crack if struck or dropped.
 Store the watch away from jewelry, as diamonds can scratch the
- Store the watch in a separate box lined with soft fabric.

crystal.

TECHNICAL CHARACTERISTICS

Case diameter	46 mm
Case material	Steel 316L
Strap width	24 – 22 mm
Strap material	Genuine leather
Type of glass	Sapphire crystal
Accuracy under normal temperature	- 15+40 seconds per day
Movement	Mechanical movement, manually wound, caliber 3603, 18 jewels
Power reserve	up to 40 hours
Water resistance	5 ATM